


# ELEMENT / ELEMENT XP QUICK START GUIDE



1

## CONNECT

- Connect the Element/Element XP.



Harman PS0913DC  
Power Supply



Optional ----->



**DigiTech**  
by HARMAN

DOWNLOAD THE OWNER'S MANUAL AT [DIGITECH.COM](http://DIGITECH.COM)

**DigiTech**  
by HARMAN

## 2

## TUNE

- Press and hold both **FOOTSWITCHES** for 2 seconds to access the tuner.
- Tune your guitar.
- Press either **FOOTSWITCH** to exit the tuner.



## 3

## SELECT PRESET

- Press the **UP** or **DOWN FOOTSWITCH** to navigate presets.



## 4

## CUSTOMIZE PRESET

- Press the **TONE BANK BUTTON** to edit your tone or **FX BANK BUTTON** to edit your effects.
- Use the **EDIT BUTTONS** to select the effect to edit.
- Turn the **DATA ENCODER** to edit the selected effect.
- Press the **STORE BUTTON** twice to store the changes to a preset.



## 5

## PLAY



## 6

## ACTIVATE DRUMS

- Press the **DRUMS BUTTON** to activate the built-in drums.

